

# Towbar/Trailer module coding

If a towbar is installed, set options in the following modules:

- Astra-H / Zafira-B

## Modules

- REC (Security code needed)
- DIS
- IPC (Security code needed)

## Variant Coding

### REC

- Set Trailer Reversing lamp control to Present
- Set Trailer Fog lamp control to Present

### DIS

- Set Towbar To Present

### IPC

- Set Towbar To Present

- Vectra-C / Signum

## Modules

- REC (Security code needed)
- DIS
- IPC (Security code needed)

## Variant Coding

### REC

- Set Trailer Reversing lamp control to Present
- Set Trailer Fog lamp control to Present

### DIS

- Set Check Control To Present

- Set Towbar To Present

IPC

Identifier "0x0???"

- Set Towbar To Present

Identifier "0x1???"

- No variant coding needed